



CONNECTOR PIN ALLOCATIONS

- 1 - From ECU Ignition Output (Coil Outputs A & D)
- 2 - +12V (Ignition Switched)
- 3 - From ECU Ignition Output (Coil Outputs B & C)
- 4 - Power Ground - Connect to Engine Block

NOTE - This igniter and coil combination uses ECU controlled dwell time. It includes 2 igniter channels and 2 dual ended coils. Great for 4 cylinder applications (use 2 for 8 cylinder applications).