





## Pressure Vs Voltage



### NOTES:

Absolute his sensor will read a vacuum & positive pressure.

This is an active sensor. Do not use a pull-up resistor on the signal of this sensor. The output is driven to the correct voltage by the electronics inside the sensor.



### APPLICATIONS:

MAP sensor on boosted engines.  
Maximum positive pressure of 45.3PSI

This sensor has a stainless steel body.